
INSTALLATION GUIDE OUTHAUL SYSTEM +



FIXTHE POINT-7 ADJUSTABLE OUTHAUL SYSTEM + ON A BOOM